

Installation of a CorrPakBPS polyethylene film container liner inside a 20 foot export container:

To ensure a "picture perfect" container liner installation, please download, view or print our [HANGING INSTRUCTIONS CHECKLIST](#) and mark off each item as it is completed.



Place folded liner on the floor of a CLEAN and SOUND container.

Unfold liner to nose of container, and insert bar into sleeve at floor.
(To use a bar in the sleeve, merely slip the bar through the sleeve, and place it in the channels near nose wall of container, on the floor.)





Tie the rope from each plastic tab securely to a lash bar up near each top corner of the nose end, so that top corners of liner will reach the ceiling of the container.

Pull the rear-end of liner toward doors. (Opening fill chute and vent chute will allow air into liner, and allow liner to be pulled into place easier.)



Tie top rear corners to lash bars in the door channels, or to ceiling "D-rings", so that the top corners of the liner will reach the ceiling near the top of the door channels.

Install all four steel rear bulkhead bars into door channel by putting bars through hanging loops, and adjust rear bulkhead hanging straps as needed. Straps should be engaged loosely enough to allow movement of the bar.



Attach bulkhead ties where applicable to horizontal bars for proper positioning of liner. Pull floor level ropes tight enough to prevent bottom edge of bulkhead from reaching and interfering with door closure, then tie securely to lash bars or available "D-rings".

Installation has been completed in under 15 minutes. Liner is now ready to load.